



- Installed Fastener Schedule:**
- All windows: Install corrosion resistant #8 fasteners no more than 4" from each corner and 16" o.c. through pre-drilled holes in the side jambs of the window.
  - Fasteners must be long enough to penetrate at least 1-1/4" into framing members.

- General Notes:**
- The product shown herein is designed and manufactured to comply with the current edition of the Florida building code.
  - Buck, framing and masonry by others and its responsibility of architect or engineer of record
  - All glazing shall conform to ASTM E1300.
  - At minimum, glazing shall be single strength annealed insulating glass.

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to [www.jeld-wen.com/resources/installation](http://www.jeld-wen.com/resources/installation).

**DISCLAIMER:**  
This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

REVISION		PROJECT ENGINEER:		DATE:	PLANT NAME AND LOCATION:	
		J. HAWKINS	2/20/13	Bend-OR		
		DRAWN BY:	J. HAWKINS	SCALE:	NTS	
		CHECKED BY:	D. STOKES	TITLE:		
		APPROVED BY:	D. YAGLA	Custom Clad Pocket Double Hung (Concealed Tilt Latch)		
		PART/PROJECT No.:	-	Thru Jamb Installation (49-3/8" x 78 3/8")		
		IDENTIFIER No.:	-	CAD DWG. No.:	REV	SHEET
				Cust/CLPKTDH Gcrt	NULL	

**JELD-WEN** 3737 LAKEPORT BLVD.  
KIAMATH FALLS OR, 97601  
PHONE: (541) 882-3451