


# THROUGH FRAME INSTALLATION



MAXIM	UM FRAME	DP	IMPACT
149	x 98	+35/-35	NO

# Installation Notes:

- Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- Use #10 PH or greater fastener through the head & side jambs with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
- Use #9 x 2-1/2" PH screws two (2) per hinge into the jambs.
- Use #8 x 2" PH fastener at each mullion (min. S.G = 0.42).
- Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

# **General Notes:**

- The product shown herein is designed tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the current Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.

TITLE:

Use structural or composite shims where required.

This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adjacent to the seal.

Printed copies of this document are not considered signed and sealed and the signature must be verified on any electronic copies



08/26/2024 TELDWEN KLAMATH FALLS OR, 97601 DRAWN BY SCALE: NTS

> Contours Steel Wood Swinging Door Inswing 4 Panel OXXO


D015859 REPORT No.: NCTL-210-3804-3


CAD DWG. No.:

SHEET 1 of 10

3737 LAKEPORT BLVD.

PHONE: (800) 535-3936





MAXIMUM FRAME	DP	IMPACT
149 x 98	+35/-35	NO

# Installation Notes:

Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).

TYP.

5" FROM

TYP.

- Use (2) #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a minimum of 1 1/2" into the buck. For 2x wood frame substrate (min. S.G. = 0.42).
- Use (2) #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visability or collateral damage to product.
- Use #9 x 2-1/2" PH screw two (2) per hinge into the jambs.

TYPICAL ELEVATION WITH FASTENER SPACING

Use #8 x 2" PH fastener at each mullion (min. S.G. = 0.42).

Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

3" & 6" FROM CENTERLINE-

SCREWS

CORNERS

TYP


This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.


# **General Notes:**

- The product shown herein is designed tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the current Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- Use structural or composite shims where required.
- Masonry strap specifications: 20 Ga. galvanized steel, .036" min. thickness x 1.5" min. width.


This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adjacent to the seal.

William S. W. Alle							
TO EN SE		DATE: 08/2	26/2024	iri d		373	37 LAKEPORT BLVD. TH FALLS OR, 97601
★ No93573 ★	DRAWN BY: M.HAM	SCALE:	NTS	لاحانال	VV ALL	PHO	NE: (800) 535-3936
TO * CE	CHECKED BY: D.VEZO	TITLE:					
TO CORIDACION	APPROVED BY: D.VEZO	Contours Steel Wood Swinging Door Inswing 4 Panel OXXO					or
MICAH SWARTZ4, FOW AL  PE No. 93573 5134 Cambridge Ct. 08/28/24	D015859			Triswing	T T dilet OX	λΟ	
5134 Cambridge Ct. 08/28/24 Klamath Falls, OR. 97603 (541) 363-8075	REPORT No.: NCTL-210-3804-3	3		CAD DWG	. No.:	REV: C	SHEET 2 of 10





# CONCRETE/MASONRY INSTALLATION



MAXIMUM FRAME	DP	IMPACT
149 x 98	+35/-35	NO

# Installation Notes:

- 1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- Use 1/4" tapcon or equivalent fasteners through frame with sufficient length to penetrate a minimum of 1 1/4" into concrete or masonry at each location with a 2 1/2" min. from edge distance. For concrete (min. fc = 3000 psi) or masonry substrate (CMU shall adhere to ASTM C90).
- Use #9 x 2-1/2" PH screw two (2) per hinge into the jambs.
- 4. Use #8 x 2" PH fastener at each mullion (min. S.G. = 0.42).
- 5. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

#### DISCLAIMER


This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

# **General Notes:**

- The product shown herein is designed, tested and manufactured to comply with the wind load criteria
  of the adopted International Building Code (IBC), the International Residential Code (IRC), the current
  Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- Use structural or composite shims where required.

This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adiacent to the seal.

Printed copies of this document are not considered signed and sealed and the signature must be verified on any electronic copies



	08/26/2024	TET TAWEN
WN BY: <b>HAM</b>	SCALE: NTS	July Will
CKED BY:	TITLE:	


3737 LAKEPORT BLVD.
 KLAMATH FALLS OR, 97601
 PHONE; (800) 535-3936


Swinging Door

Contours Steel Wood Swinging Door Inswing 4 Panel OXXO


REPORT No.: CAD DWG, No.: NCTL-210-3804-3

REV: C SHEET 3 of 10





# CONCRETE/MASONRY INSTALLATION



MAXIMUM FRAME	DP	IMPACT
149 x 98	+35/-35	NO

# Installation Notes:

- 1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- Use (1) 1/4" Tapcon or equivalent fasteners through strap with sufficient length to penetrate a minimum of 1 1/4" into concrete or masonry at each location with a 2 1/2" min. from edge distance. Use (2) #8 PFH fasteners through masonry strap into frame. For concrete (min. fc = 3000 psi) or masonry substrate (CMU shall adhere to ASTM C90).
- 3. Use #9 x 2-1/2" PH screw two (2) per hinge into the jambs.
- 4. Use #8 x 2" PH fastener at each mullion (min. S.G. = 0.42).
- 5. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

MICAH SWARTZ, FOW A

08/28/24

PE No. 93573 5134 Cambridge Ct.
Klamath Falls, OR. 97603 (541) 363-8075

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

#### DISCLAIMER

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

# **General Notes:**


- The product shown herein is designed, tested and manufactured to comply with the wind load criteria
  of the adopted International Building Code (IBC), the International Residential Code (IRC), the current
  Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- Use structural or composite shims where required.
- 4. Masonry strap specifications: 20 Ga. galvanized steel, .036" min. thickness x 1.5" min. width.

This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adjacent to the seal.

1111		DATE: 08/26/2024	3737 LAKEPORT BLV  TELDWEN KLAMATH FALLS OR, 976	/D.		
	DRAWN BY: M.HAM	SCALE: NTS	PHONE: (800) 535-39			
¥ ,	CHECKED BY: D.VEZO	TITLE:				
111111	APPROVED BY: D.VEZO		Contours Steel Wood Swinging Door Inswing 4 Panel OXXO			
	D015859		Inswing 4 ratio OAAO			
1	REPORT No.: NCTL-210-3804-	3	CAD DWG. No.:  REV: C SHEET 4 of 10			

**IMPACT** 

+35/-35



# Installation Notes:

1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).

3" EPOM

5" FROM

CORNERS

- Use min. (2) #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a
  minimum of 1 1/2" into the buck. Bend straps around both sides of the buck. For 2x wood frame
  substrate (min. S.G. = 0.42).
- 3. Use min. (2) #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visability or collateral damage to product.
- 4. Use #9 x 2-1/2" PH screw two (2) per hinge into the jambs.

TYPICAL ELEVATION WITH FASTENER SPACING

5. Use #8 x 2" PH fastener at each mullion (min. S.G. = 0.42).

6. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record to the project of installation.

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

3" & 6" FROM

HINGE

TYP.

#### DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.


# General Notes:

- 1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the current Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- 3. Use structural or composite shims where required.
- 4. Masonry strap specifications: 20 Ga. galvanized steel, .036" min. thickness x 1.5" min. width.


MAXIMUM FRAME


149 x 98

This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adjacent to the seal.










# THROUGH FRAME INSTALLATION



MAXIMUM	FRAME	DP	IMPACT
149 x	97	+35/-35	NO

# Installation Notes:

- 1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- Use #10 PH or greater fastener through the head & side jambs with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
- 3. Use #9 x 2-1/2" PH screws two (2) per hinge into the jambs.
- 4. Use #8 x 2" PH fastener at each mullion (min. S.G = 0.42).
- 5. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

#### DISCLAIMER


This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

# **General Notes:**

- The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the current Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- Use structural or composite shims where required.

This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adiacent to the seal.

Printed copies of this document are not considered signed and sealed and the signature must be verified on any electronic copies



		08/26/2024	TET DAVEN
	DRAWN BY: M.HAM	SCALE: NTS	JELE WEIT
1	CHECKED BY: D.VEZO	TITLE:	


KLAMATH FALLS OR, 97601 PHONE: (800) 535-3936


Contours Steel Wood Swinging Door Outswing 4 Panel OXXO

REPORT No.: CAD DWG, No.: NCTL-210-3804-4

REV: C SHEET 6 of 10

3737 LAKEPORT BLVD.





MAXIMUM FRAME	DP	IMPACT
149 x 97	+35/-35	NO

# Installation Notes:

1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).

TYP.

5" FROM

TYP.

- Use (2) #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a minimum of 1 1/2" into the buck. For 2x wood frame substrate (min. S.G. = 0.42).
- 3. Use (2) #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visability or collateral damage to product.
- 4. Use #9 x 2-1/2" PH screw two (2) per hinge into the jambs.

TYPICAL ELEVATION WITH FASTENER SPACING

5. Use #8 x 2" PH fastener at each mullion (min. S.G. = 0.42).

6. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

MICAH SWARTZ, FOW A

08/28/24

PE No. 93573 5134 Cambridge Ct.
Klamath Falls, OR. 97603 (541) 363-8075

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

3" & 6" FROM CENTERLINE-

SCREWS

CORNERS

TYP

## DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.


# **General Notes:**

- The product shown herein is designed, tested and manufactured to comply with the wind load criteria
  of the adopted International Building Code (IBC), the International Residential Code (IRC), the current
  Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- Use structural or composite shims where required.
- 4. Masonry strap specifications: 20 Ga. galvanized steel, .036" min. thickness x 1.5" min. width.


This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adjacent to the seal.

1111		DATE: 08/26/2024	IFI D-WFI	373	37 LAKEPORT BLVD. TH FALLS OR, 97601	
M1111	DRAWN BY: M.HAM	SCALE: NTS	Julius Willi		NE: (800) 535-3936	
	CHECKED BY: D.VEZO	TITLE;				
11111	APPROVED BY: D.VEZO		Contours Steel Wood Swinging Door Outswing 4 Panel OXXO			
	D015859		Outswing 4 raner o	XXO		
ļ	REPORT No.: NCTL-210-3804-	4	CAD DWG, No.:	REV: C	<sup>SHEET</sup> 7 of 10	

# CORNERS 3" & 6" FROM 3" & 6" FROM -CORNERS 17.5" O.C. TYPICAL ELEVATION WITH FASTENER SPACING



# CONCRETE/MASONRY INSTALLATION



MAXIMUM FRAME	DP	IMPACT
149 x 97	+35/-35	NO

# Installation Notes:

- 1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- Use 1/4" tapcon or equivalent fasteners through frame with sufficient length to penetrate a minimum of 1 1/4" into concrete or masonry at each location with a 2 1/2" min. from edge distance. For concrete (min. fc = 3000 psi) or masonry substrate (CMU shall adhere to ASTM C90).
- Use #9 x 2-1/2" PH screw two (2) per hinge into the jambs.
- 4. Use #8 x 2" PH fastener at each mullion (min. S.G. = 0.42).
- 5. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

#### DISCLAIMER

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.


# **General Notes:**


- . The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the current Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- Use structural or composite shims where required.

This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adjacent to the seal.




	DATE: 08/2	26/2024	TET		<b>T</b> 3	737 LAKEPORT BLVD. ATH FALLS OR, 97601
DRAWN BY: M.HAM	SCALE:	NTS	عندل ا	TA AA TTI.	4	ONE: (800) 535-3936
CHECKED BY: D.VEZO	TITLE:		<u> </u>	GL 134 1G :		
APPROVED BY: D.VEZO	Contours Steel Wood Swinging Door Outswing 4 Panel OXXO					
D015859				tswing 11 dilei 02		
REPORT No.: NCTL-210-3804-	4			CAD DWG, No.:	REV: C	SHEET 8 of 10





# CONCRETE/MASONRY INSTALLATION



MAXIMUM FRAME	DP	IMPACT
149 x 97	+35/-35	NO

# Installation Notes:

- 1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- Use (1) 1/4" Tapcon or equivalent fasteners through strap with sufficient length to penetrate a minimum of 1 1/4" into concrete or masonry at each location with a 2 1/2" min. from edge distance. Use (2) #8 PFH fasteners through masonry strap into frame. For concrete (min. fc = 3000 psi) or masonry substrate (CMU shall adhere to ASTM C90).
- 3. Use #9 x 2-1/2" PH screw two (2) per hinge into the jambs.
- Use #8 x 2" PH fastener at each mullion (min. S.G. = 0.42).
- 5. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

MICAH SWARTZ, FOW A

08/28/24

PE No. 93573 5134 Cambridge Ct.
Klamath Falls, OR. 97603 (541) 363-8075

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

## DISCLAIMER:


This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.


# **General Notes:**

- The product shown herein is designed, tested and manufactured to comply with the wind load criteria
  of the adopted International Building Code (IBC), the International Residential Code (IRC), the current
  Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- 3. Use structural or composite shims where required.
- 4. Masonry strap specifications: 20 Ga. galvanized steel, .036" min. thickness x 1.5" min. width.

This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adjacent to the seal.

IIII		DATE: 08/26/2024	3737 LAKEPORT BLVD.  KLAMATH FALLS OR, 97601		
*	DRAWN BY: M.HAM	SCALE: NTS	JCLLS WCIN KLAMATH FALLS OR, 97601 PHONE: (800) 535-3936		
FR	CHECKED BY: D.VEZO	TITLE:			
111111	APPROVED BY: D.VEZO	Contours Steel Wood Swinging Door Outswing 4 Panel OXXO			
	D015859		Outswing 4 Fallel OAAO		
4	REPORT No.: NCTL-210-3804-	4	CAD DWG. No.: REV: C SHEET 9 of 10		





DP	IMPACT
+35/-35	NO
	DP +35/-35

# **Installation Notes:**

3" & 6" FROM

CENTERI INE-

HINGE

TYP.

- 1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- 2. Use min. (2) #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a minimum of 1 1/2" into the buck. Bend straps around both sides of the buck. For 2x wood frame substrate (min. S.G. = 0.42).

3" EPOM

5" FROM

CORNERS

- 3. Use min. (2) #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visability or collateral damage to product.
- 4. Use #9 x 2-1/2" PH screw two (2) per hinge into the jambs.

TYPICAL ELEVATION WITH FASTENER SPACING

5. Use #8 x 2" PH fastener at each mullion (min. S.G. = 0.42).

6. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record by the project of installation.

MICAH SWARTZ, POWAL

08/28/24

PE No. 93573 771111 5134 Cambridge Ct. Klamath Falls, OR. 97603

(541) 363-8075

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

# DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

# **General Notes:**

- The product shown herein is designed, tested and manufactured to comply with the wind load criteria
  of the adopted International Building Code (IBC), the International Residential Code (IRC), the current
  Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- 3. Use structural or composite shims where required.
- 4. Masonry strap specifications: 20 Ga. galvanized steel, .036" min. thickness x 1.5" min. width.

This item has been digitally signed and sealed by Micah Swartz, P.E. on the date adjacent to the seal.

		DATE: 08/26/2024	IFI D-WI	3737 LAKEPORT BLVD. KLAMATH FALLS OR, 97601	
	DRAWN BY: M.HAM	SCALE: NTS	Jailie VV B	PHONE: (800) 535-3936	
-	CHECKED BY: D.VEZO	TITLE:			
	APPROVED BY: D.VEZO	Contours Steel Wood Swinging Door Outswing 4 Panel OXXO			
	D015859		Outswing 4 rand	EI OAAO	
	NCTL-210-3804-	4	CAD DWG, No.:	REV: C SHEE 10 of 10	