





45	
45 3/8	Max
×	
91	Frame
7	)e
/32	
+35/	D
/-35	P
NO	IMPACT

## Installed Fastener Schedule:

TYPICAL ELEVATION WITH FASTENER SPACING

- pre-drilled holes in the head and side jambs of the window. All windows: install corrosion resistant #8 fasteners no more than 4" from each corner and 16" o.c. through
- 2 Fasteners must be long enough to penetrate at least 1-1/2" into framing members.

## General Notes:

- Florida building code. The product shown herein is designed and manufactured to comply with the current edition of the
- Buck, framing and masonry by others and is responsibility of architect or engineer of record All glazing shall conform to ASTM E1300.

ωΝ

SitelineCLPKTDH Cert			1	except as authorized by JEED-WEINING.
CAD DWG. No.: REV: A SHEET			IDENTIFIER No.	reproduced or copied in whole or in part or used or disclosed to others
			D015173	This drawing and its contents are confidential and are not to be
			PART/PROJECT No.:	DISCLAIMER:
			D.STOKES	unit or go to www.jeld-wen.com.
Siteline clad Pocket Double Hung	Site		APPROVED BY:	complete installation procedure, see the instructions packaged with the
	) F		R.HAMILTON	consideration that may arise in different wall conditions. For the
		TITLE	CHECKED BY:	applicable) up to the size littleauous noted. It is not littleau as a guide
PHONE: (800) 535-3936	_	NTS	J HAWKINS	to achieve the rated design pressure and impact performance (where
KLAMATH FALLS OR, 97601		SCALE:	DRAWN BY	This schedule addresses only the fasteners required to anchor the unit
T 3737 LAKEPORT BLVD.	_	05/16/2018		