





THROUGH FRAME INSTALLATION

66 Max ∞ <u>Frame</u> +50/ P /-55MPACT N 0

Installed Fastener Schedule:

TYPICAL ELEVATION WITH FASTENER SPACING

- pre-drilled holes in the head and side jambs of the window. All windows: install corrosion resistant #8 fasteners no more than 4" from each corner and 16" o.c. through
- 2 Fasteners must be long enough to penetrate at least 1-1/2" into framing members.

General Notes:

- Florida building code. The product shown herein is designed and manufactured to comply with the current edition of the
- Buck, framing and masonry by others and is responsibility of architect or engineer of record All glazing shall conform to ASTM E1300.

ωΝ

SitelineWDPKTDPW Cert		•		evoobt as annivirga by attp-yything.
CAD DWG. No.:		IDENTIFIER No.		reproduced or copied in whole or in part or used or disclosed to others
		D015189		This drawing and its contents are confidential and are not to be
		PART/PROJECT No.		DISCLAIMER:
		D.STOKES		unit or go to www.jeld-wen.com.
Siteline Wood Pocket DH Pict		APPROVED BY:	e	complete installation procedure, see the instructions packaged with the
	2	R.HAMILTON		consideration that may arise in different wall conditions. For the
	TITLE	CHECKED BY:		applicable) up to the size limitations not address the sealing
	NIS	J.HAWKINS	7	to achieve the rated design pressure and impact performance (where
	SCALE:	DRAWN BY:		This schedule addresses only the fasteners required to anchor the unit
	02/1//2010			

נכוווינ אאססמיי סרצכני ביוויי וינימיני אאווימסא	C	ES :
Citaling Wood Dookot DE Digt is Window	<u>0</u>	LTON
	TITLE	
PHONE: (800) 535-3936	NTS	SNE
→ JEANA IN TAFFU ON, WYOOL	SCALE:	
	05/1//2018	
3737 LAKEPORT BLVD.	DATE:	

REV