





THROUGH FRAME INSTALLATION

60 × 84	Max Frame	
+35/-40	DP	
NO	IMPACT	

TYPICAL ELEVATION WITH FASTENER SPACING

- Installed Fastener Schedule: pre-drilled holes in all jambs of the window. All windows: install corrosion resistant #8 fasteners no more than 4" from each corner and 16" o.c. through
- 2 Fasteners must be long enough to penetrate at least 1-1/2" into framing members.

General Notes:

- Florida building code. The product shown herein is designed and manufactured to comply with the current edition of the
- Buck, framing and masonry by others and is responsibility of architect or engineer of record
- ωΝ All glazing shall conform to ASTM E1300.

ı	IDENTIFIER No.	PART/PROJECT No.: D015230	D.STOKES	APPROVED BY:	K.CAMPBELL	CHECKED BY:	J.HAWKINS	DRAWN BY:			
			Sit			NTS	SCALE:	00/22/2010	06/22/2010	DATE	
		teline Woo				Ç		L			
SitelineWDPStaCsmt Cert	CAD DWG. No.	Siteline Wood Pocket Stationary Casement								1 1 1 1 1	
I	REV: A	згу Саз				PH(Z LAIV		-1 ω		
	SHEET			ement	-		PHONE: (800) 535-3936	ALLI FALLS OR, 97001	ATH EALLS ON 07601	3/3/ LAKEPORT BLVD.	

SitelineWDPStaCsmt Cert

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

complete installation procedure, see the instructions packaged with the

consideration that may arise in different wall conditions. For the to the installation process and does not address the sealing applicable) up to the size limitations noted. It is not intended as a guide to achieve the rated design pressure and impact performance (where This schedule addresses only the fasteners required to anchor the unit

unit or go to www.jeld-wen.com.