





SILL

$77 \ 3/8 \times 94 \ 11/16$	Max Frame	OPERATING POCKET
/16 + / - 35	DP	DH PICTURE
NO	IMPACT	URE

Installed Fastener Schedule:

- All windows: install corrosion resistant #8 fasteners no more than 4" from each cornor and 16" o.c. through pre-drilled holes in the head and side jambs of the window.
- Ņ Fasteners must be long enough to penetrate at least 1-1/4" into framing members.

General Notes:

- Florida building code. The product shown herein is designed and manufactured to comply with the current edition of the
- Buck, framing and masonry by others and is responsibility of architect or engineer of record All glazing shall conform to ASTM E1300.
- At minimum, glazing shall be single strength annealed insulating glass.