



Max Frame	DP	IMPACT
36 x 72	+/-65	NO

- Installed Fastener Schedule:**
- All windows: install corrosion resistant #8 fasteners no more than 4" from each corner and 16" o.c. through the jambs on all sides of the window. Fasteners must be long enough to penetrate at least 1 1/2" into framing members.

- General Notes:**
- The product shown herein is designed and manufactured to comply with the current edition of the Florida building code.
 - Buck, framing and masonry by others and is responsibility of architect or engineer of record.

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com.

DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER: J. Hawkins	DATE: 04/13/15	JELD-WEN	3737 Lakeport Blvd Klamath Falls, OR, 97601 Phone: 800-535-3936
DRAWN BY: J. Allen	SCALE: NTS		
CHECKED BY: D. Vezo	TITLE: Custom Wood Casement Operator Thru Jamb Installation (36" x 72")		
APPROVED BY: J. Kantola			
PART/PROJECT No.: D0092290	PLANT NAME AND LOCATION: Bend, Oregon	CAD DWG. No.: CustWdCaseOpenInstall	REV: 00
IDENTIFIER No.: NA			SHEET 1 of 1 .