



TYPICAL ELEVATION WITH FASTENER SPACING



1/4" MAX. SHIM SPACE

THROUGH FRAME INSTALLATION



FRAME JAMB SECTION (TYP) HORIZONTAL SECTION

MAXIMUM FRAME	DP	IMPACT
71 1/4 x 106 1/2	+50/-50	NO

Installation Notes:

1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
2. Use #8 PH or greater fastener through the head & side jambs with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

General Notes:

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the current Florida Building Code (FBC) and the industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. Use structural or composite shims where required.


This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance. (Where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

DISCLAIMER:



This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

"AS TESTED"

DATE: 07/13/2021	DRAWN BY: J.HAWKINS	RECORD NO.: D014104	REPORT NO.: M2382.01-301-47-R0
SCALE: NTS	CHECKED BY: C.ABBOTT	APPROVED BY: D.STOKES	CAD DWG. NO.: Sletline\VDSPD\Mull Car
TITLE: Sletline Wood Wide Sile Sliding Door Mullion		REV: A	SHEET 1 OF 2
3737 LAKEPORT BLVD. KLAMATH FALLS OR, 97601 PHONE: (800) 535-3936			



TYPICAL ELEVATION WITH FASTENER SPACING



MASONRY STRAP INSTALLATION

Installation Notes:

1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
2. Use 2 - #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a minimum of 1 1/2" into the masonry or buck.. For concrete (min. fc = 2000 psi) or masonry substrate (CMU shall adhere to ASTM C90).
3. Use 2 - #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visibility or collateral damage to product.
4. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

General Notes:

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the current Florida Building Code (FBC) and the industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. Use structural or composite shims where required.
4. Masonry strap specifications: 20 Ga. galvanized steel, .096" min. thickness x 1.5" min. width.

MAXIMUM FRAME	DP	IMPACT
71 1/4 x 106 1/2	+50/-50	NO

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

DISCLAIMER:
This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

<p>RECORD No.: D014104</p> <p>APPROVED BY: D.STOKES</p> <p>CHECKED BY: C.ABBOTT</p> <p>DRAWN BY: J.HAWKINS</p>	<p>DATE: 07/13/2021</p> <p>SCALE: NTS</p> <p>TITLE: Siteline Wood Wide Stile Sliding Door Mullion</p>	<p>3737 LAKEPORT BLVD. KLAMATH FALLS OR, 97601 PHONE: (800) 535-3936</p>
<p>REPORT No.: M2382.01-301-47-R0</p> <p>CAD DWG. No.: StelIneWIDSPDMull Car</p> <p>REV: A</p>	<p>SHEET 2 OF 2</p>	<p>"AS TESTED"</p>