

NAIL FIN INSTALLATION

Max Frame	DP RATING	IMPACT
60" x 60"	+50/-55	NO

Installation Notes:

1. Seal flange/frame to substrate.
2. Use #8 PH or greater fastener through the nail fin with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2X wood frame substrate (min. S.G. = 0.42).
3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

General Notes:

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code(IBC), the International Residential Code(IRC), the Florida Building Code(FBC) and the industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be 3.0mm annealed - 12.45mm airspace - 3.0mm annealed.
4. Use structural or composite shims where required.

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com.

DISCLAIMER:




This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER:	DATE:	07/19/17
DRAWN BY:	SCALE:	NTS
A. McMILLAN	TITLE:	Premium Vinyl Fixed with Sloped Sill Window
CHECKED BY:	J. GOOSSSEN	
APPROVED BY:	J. GOOSSSEN	
PART/PROJECT NO.:	D008147	
IDENTIFIER NO.:	110-16-137	
PLANT NAME AND LOCATION:	CAD DWG. No.:	REV: 00
		SHEET 1 OF 4

JELD-WEN

3737 Lakeport Blvd
Klamath Falls, OR, 97601
Phone: (800) 535-3936

**MASONRY STRAP
INSTALLATION**



Max Frame	DP RATING	IMPACT
60" X 60"	+50/-55	NO

Installation Notes:

1. Seal flange/frame to substrate.
2. Install masonry straps to vinyl frame using (4)#8 x 1/2" PH corrosion resistant fasteners. Bend straps around buck and secure with (2)#8 fastener thru masonry strap into wood buck. Fasteners must be long enough to penetrate at least 1 1/2" into framing members. For 2X wood frame substrate (min. S.G. = 0.42)
3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

General Notes:

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code(IBC), the International Residential Code(IRC), the Florida Building Code(FBC) and the industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be 3.0mm annealed - 12.45mm airspace - 3.0mm annealed.
4. Use structural or composite shims where required.

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com.

DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER: A. McMILLAN	DATE: 07/19/17	JELD-WEN	3737 Lakeport Blvd Klamath Falls, OR, 97601 Phone: (800) 535-3936
DRAWN BY: A. McMILLAN	SCALE: NTS		
CHECKED BY: J. GOOSSSEN	TITLE: Premium Vinyl Fixed with Sloped Sill Window		
APPROVED BY: J. GOOSSSEN			
PART/PROJECT NO.: D008147			
IDENTIFIER NO.: 110-16-137	PLANT NAME AND LOCATION:	CAD DWG. No.:	REV: 00 SHEET 2 OF 4