
16" O.C. TYP. CONNERS 16" O.C. TYP.

TYPICAL ELEVATION WITH FASTENER SPACING



EMBEDMENT 1/4" MAX. SHIM SPACE 1/4" MAX. SHIM SPACE FRAME JAMB SECTION (TYP)

MASONRY STRAP INSTALLATION

84 × 84	Max Frame	
+50/-50	DP	
NO	IMPACT	

Installation Notes:

- 1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk when no fastener is used to anchor the sill (typical).
- Use 2 #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a minimum of 1 1/2" into the buck. For 2x wood frame substrate (min. S.G. = 0.42).
- Use 2 #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visability or collateral damage to product.
- Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

General Notes:

- The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the current Florida Building Code (FBC) and the industry requirement for the stated conditions.
- All glazing shall conform to ASTM E1300.
- Use structural or composite shims where required.

α ω 4

Masonry strap specifications: 20 Ga. galvanized steel, .096" min. thickness x 1.5" min. width.

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

SCLAIMER

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

"AS TESTED

SHEET 1 of 1	REV: A	CAD DWG. No.: SitelineWDDirectSet Cert		REPORT No.:
				D003707
	VIndow	Siteline Wood Direct Set Window		APPROVED BY: D.STOKES
			пте:	CHECKED BY K. CAMPBELL
PHONE: (800) 535-3936	PHONE		SCALE: NTS	J HAWKINS
3737 LAKEPORT BLVD.	3737	3737 LAKEPORT BLVD.	01/07/2020	