





THROUGH FRAME

INSTALLATION

Seal flange/frame to substrate.

Installed Fastener Schedule:

framing members. the nail fins on all sides of the window. Fasteners must be long enough to penetrate at least 1 1/4" into All windows: install corrosion resistant #8 fasteners no more than 4" from each corner and 16" o.c. through

General Notes:

the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC) and the industry standard requirement for the stated conditions. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of

NO

- αω4 Buck, framing and masonry by others and is responsibility of architect or engineer of record
 - All glazing shall conform to ASTM E1300.
- At minimum, glazing shall be double strength annealed insulating glass.

packaged with the door or go to not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions noted. It is not intended as a guide to the installation process and does window to achieve the rated design pressure up to the size limitations This schedule addresses only the fasteners required to anchor the

www.jeld-wen.com/resources/installation

DISCLAIMER:

except as authorized by JELD-WEN Inc. This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others

SHEET	REV:	CAD DWG. No.:	TION:	Rantoul, IL	IDENTIFIER NO. N/A
					PART/PROJECT NO.: D012040
indow	ğ	Sitelline wood Double Hung Window	Siteline		APPROVED BY: D. Stokes
	1 1 1			TITLE:	CHECKED BY: J. Jones
Phone: (541) 882-3451				SCALE: NTS	D. Vezo
3737 Lakeport Blvd	_	namel ia		01/19/2015	PROJECT ENGINEER: