

NAIL FIN INSTALLATION

Max Frame	DP	IMPACT
146 1/16" x 95 1/2"	+/-40	NO

Installation Notes:

1. Seal flange/frame to substrate.
2. Use #8 PH or greater fastener through the nailfin head and sides with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.
4. Use #8 x 2" PH or greater fasteners through channel guide, bracket and head jamb into wood framing. Install screws in every pre-drilled hole.

General Notes:



1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC), and the Industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be double strength annealed insulating glass.
4. Use structural or composite shims where required.

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com/resources/installation.

DISCLAIMER:


This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER: —	DATE: 02/14/2017		3737 Lakeport Blvd Klamath Falls, OR, 97601 Phone: (800) 535-3936
DRAWN BY: J.HAWKINS	SCALE: NTS		
CHECKED BY: C.GRAETSCH	TITLE: Steline Clad Sliding Door Low Profile Sill Mullion		
APPROVED BY: D.STOKES			
PART/PROJECT No: D014584	PLANT NAME AND LOCATION: Hawkins-WI	CAD DWG. No.:	REV:
IDENTIFIER NO.:		StellineC.SPDL.PMull Cer	A
			SHEET



FRAME SECTION (TYP)
VERTICAL SECTION

NOTE: Gasket between Frame & Wood Opening.



JAMB SECTION (TYP)
HORIZONTAL SECTION

NOTE: Gasket between Mullion Frame & Wood Opening.

Max Frame	DP	IMPACT
146 1/16" x 95 1/2" + /-40		NO

Installation Notes:

1. Seal frame to substrate.
2. Use #8 PH or greater fastener through the head and side jambos with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.
4. Use #8 PH or greater fastener through channel guide, bracket and head jamb into wood framing. Install screws in every pre-drilled hole.

General Notes:

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC), and the Industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be double strength annealed insulating glass.
4. Use structural or composite shims where required.




This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com/resources/installation.

DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER: --	DATE: 04/14/2017	JELD-WEN	3737 Lakeport Blvd Klamath Falls, OR, 97601 Phone: (800) 535-3936
DRAWN BY: J.HAWKINS	SCALE: NTS		
CHECKED BY: C.GRAETSCH	TITLE: Steline Clad Sliding Door Low Profile Sill Mullion		
APPROVED BY: D.STOKES			
PART/PROJECT No.: D014584	PLANT NAME AND LOCATION: Hawkins-WI	CAD DWG. No.: StellineClSPDLP Cert	REV: A SHEET

**MASONRY STRAP
INSTALLATION**



Max Frame	DP	IMPACT
146 1/16" x 95 1/2"	+/-40	NO

Installation Notes:

1. Seal frame to substrate.
2. Use #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a minimum of 1 1/2" into the masonry or buck.. For concrete (min. fc = 3000 psi) or masonry substrate (CMU shall adhere to ASTM C90).
3. Use #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visibility or collateral damage to product.
4. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.
5. Use #8 x 2" PH or greater fasteners through channel guide, brackets and head jamb into wood framing. Install screws in every pre-drilled hole.

General Notes:

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC), and the Industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be double strength annealed insulating glass.
4. Use structural or composite shims where required.

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to www.jeld-wen.com/resources/installation.

DISCLAIMER:
This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER: ---	DATE: 04/14/2017	JELD-WEN	3737 Lakeport Blvd Klamath Falls, OR, 97601 Phone: (800) 535-3936
DRAWN BY: J.HAWKINS	SCALE: NTS		
CHECKED BY: C.GRAETSCH	TITLE: Stieline Clad Sliding Door Low Profile Sill Mullion	JELD-WEN	
APPROVED BY: D.STOKES			
PART/PROJECT No.:			
IDENTIFIER No.:		PLANT NAME AND LOCATION: Hawkins-WI	CAD DWG. No.:
			StielineCSPDLP Cert
			REV: A
			SHEET