



TYPICAL ELEVATION WITH FASTENER SPACING



FRAME SECTION (TYP)  
VERTICAL SECTION  
NOTE: Caulk between Holding Flange & Wood Opening.



JAMB SECTION (TYP)  
HORIZONTAL SECTION  
NOTE: Caulk between Holding Flange & Wood Opening.

NAIL FIN INSTALLATION

Max Frame	DP	IMPACT
141 3/8" x 95 1/2"	+/-40	NO

Installation Notes:

1. Seal flange/frame to substrate.
2. Use #8 PH or greater fastener through the nailfin head and sides with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.
4. Use #8 x 2" PH or greater fasteners through channel guide, bracket and head jamb into wood framing. Install screws in every pre-drilled hole.


General Notes:

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC), and the industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be double strength annealed insulating glass.
4. Use structural or composite shims where required.


This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It's not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to [www.jeld-wen.com/resources/installation](http://www.jeld-wen.com/resources/installation).

DISCLAIMER: This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.


PROJECT ENGINEER: ---	DATE: 12/13/2016	<b>JELD-WEN</b>	3737 Lakeport Blvd Klamath Falls, OR, 97601 Phone: (800) 535-3936
DRAWN BY: J.HAWKINS	SCALE: NTS		<b>Steline Clad Quad Sliding Patio Door Low Profile Sill</b>
CHECKED BY: C.GRAETSCH	TITLE:		
APPROVED BY: D.STOKES	PART/PROJECT No.:		PLANT NAME AND LOCATION: Hawkins-WI
IDENTIFIER No.:	D014467	CAD DWG. No.:	REV: A SHEET
		StelineCladSPDL.POD.Cert	



TYPICAL ELEVATION WITH FASTENER SPACING



THRU JAMB INSTALLATION



Max Frame	DP	IMPACT
141 3/8" x 95 1/2"	+/-40	NO

**Installation Notes:**

1. Seal frame to substrate.
2. Use #8 PH or greater fastener through the head and side jambs with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.
4. Use #8 PH or greater fastener through channel guide, bracket and head jamb into wood framing. Install screws in every pre-drilled hole.


**General Notes:**

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC), and the Industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be double strength annealed insulating glass.
4. Use structural or composite shims where required.



This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It's not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to [www.jeld-wen.com/resources/installation](http://www.jeld-wen.com/resources/installation).

**DISCLAIMER:**  
This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER: ---	DATE: 4/14/2017	<b>JELD-WEN</b>	3737 Lakeport Blvd Klamath Falls, OR, 97601 Phone: (800) 535-3936
DRAWN BY: J.HAWKINS	SCALE: NTS		Stieline Clad Quad Sliding Patio Door Low Profile Sill
CHECKED BY: C.GRAETSCH	TITLE:		
APPROVED BY: D.STOKES			
PART/PROJECT No.: D014467	PLANT NAME AND LOCATION: Hawkins-WI	CAD DWG. No.: StielineClSPDL.POD.Cert	REV: A SHEET



TYPICAL ELEVATION WITH FASTENER SPACING



MASONRY INSTALLATION

**Installation Notes:**

1. Seal frame to substrate.
2. Use #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a minimum of 1 1/2" into the masonry or buck.. For concrete (min. fc = 3000 psi) or masonry substrate (CMU shall adhere to ASTM C90).
3. Use #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visibility or collateral damage to product.
4. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.
5. Use #8 x 2" PH or greater fasteners through channel guide, brackets and head jamb into wood framing. Install screws in every pre-drilled hole.

**General Notes:**

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC), and the Industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be double strength annealed insulating glass.
4. Use structural or composite shims where required.

Max Frame	DP	IMPACT
141 3/8" x 95 1/2"	+/-40	NO

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It's not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to [www.jeld-wen.com/resources/installation](http://www.jeld-wen.com/resources/installation).

**DISCLAIMER:**  
This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER: ---	DATE: 04/14/2017	<b>JELD-WEN</b> 3737 Lakeport Blvd Klamath Falls, OR, 97601 Phone: (800) 535-3936
DRAWN BY: J.HAWKINS	SCALE: NTS	
CHECKED BY: C.GRAETSCH	TITLE: Stieline Clad Quad Sliding Patio Door Low Profile Sill	
APPROVED BY: D.STOKES		
PART/PROJECT No.:	PLANT NAME AND LOCATION:	
D0114467	Hawkins-WI	
IDENTIFIER No.:	CAD DWG. No.:	REV:
----	StielineClad.POD.Cert	A
		SHEET