



TYPICAL ELEVATION WITH FASTENER SPACING



FRAME SECTION (TYP)  
VERTICAL SECTION  
NOTE: Caulk between Molding Flange & Wood Gaining.



FRAME JAMB SECTION (TYP)  
HORIZONTAL SECTION  
NOTE: Caulk between Molding Flange & Wood Gaining.

NAILFIN INSTALLATION

- Installation Notes:**
1. Seal flange/frame to substrate.
  2. Use #8 PH or greater fastener through the nailfin head and sides with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
  3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.
  4. Replace #8 x 1" fastener in stationary bracket with #8 x 2 1/2" PPH or greater fastener through stationary bracket and head jamb into wood framing.

- General Notes:**
1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC) and the Industry requirement for the stated conditions.
  2. All glazing shall conform to ASTM E 1300.
  3. At minimum, glazing shall be tempered (3.1mm) insulating glass.
  4. Use structural or composite shims where required.


Max Frame	DP	IMPACT
1 22 5/8 x 98 1/2	+35/-35	NO

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to [www.jeld-wen.com/resources/installation](http://www.jeld-wen.com/resources/installation).


**DISCLAIMER:**

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER:	DATE:	7/31/2016	3737 LAKEPORT BLVD.	
DRAWN BY:	SCALE:	NTS	KLAMATH FALLS OR, 97601	
J.HAWKINS			PHONE: (800) 535-3936	
CHECKED BY:	TITLE:	EpicVue Clad Narrow Gliding Patio Door		
C.GRAETSCH				
APPROVED BY:				
D.STOKES				
PART/PROJECT No.:	PLANT NAME AND LOCATION:			
D014241	Bend-OR	CAD DWG. No.:	REV.:	SHEET
IDENTIFIER NO.:		CJSCJLNGPD Cert	A	




TYPICAL ELEVATION WITH FASTENER SPACING



FRAME SECTION (TYP)  
VERTICAL SECTION

NOTE: Caulk between Nailing Flange & Wood Opening.



THROUGH FRAME  
INSTALLATION

NOTE: Caulk between Nailing Flange & Wood Opening.

Max Frame	DP	IMPACT
122 5/8 x 98 1/2	+35 / -35	NO

**Installation Notes:**

1. Seal flange/frame to substrate.
2. Use #8 PH or greater fastener through the head and side jambs with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
3. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.
4. Replace #8 x 1" fastener in stationary bracket with #8 x 2 1/2" PPH or greater fastener through stationary bracket and head jamb into wood framing.

**General Notes:**

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC) and the industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be tempered (3.1mm) insulating glass.
4. Use structural or composite shims where required.


This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to [www.jeld-wen.com/resources/installation](http://www.jeld-wen.com/resources/installation).

**DISCLAIMER:**

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.


PROJECT ENGINEER:		DATE: 7/31/2016	
DRAWN BY: J.HAWKINS		SCALE: NTS	
CHECKED BY: C.GRAETSCH		<p style="text-align: center;"><b>JELD-WEN</b></p> <p style="text-align: center;">3737 LAKEPORT BLVD. KLAMATH FALLS OR, 97601 PHONE: (800) 535-3936</p>	
APPROVED BY: D.STOKES			
PART/PROJECT No.: D014241			
IDENTIFIER No. --		PLANT NAME AND LOCATION: Bend-OR	CAD DWG. No.: CURJCLNGPD Car
		REV: A	SHEET
EpicVue Clad Narrow Gliding Patio Door			

MASONRY STRAP  
INSTALLATION




FRAME JAMB SECTION (TYP)  
HORIZONTAL SECTION  
NOTE: Caulk between Nailing Flange & Wood Opening.

Max Frame	DP	IMPACT
1 22 5/8 x 98 1/2	+35 / -35	NO



FRAME SECTION (TYP)  
VERTICAL SECTION  
NOTE: Caulk between Nailing Flange & Wood Opening.



TYPICAL ELEVATION WITH FASTENER SPACING

Installation Notes:

1. Seal flange/frame to substrate.
2. Use #8 PFH or larger fasteners through masonry strap with sufficient length to penetrate a minimum of 1 1/2" into the masonry or buck.. For concrete (min. fc = 3000 psi) or masonry substrate (CMU) shall adhere to ASTM C90).
3. Use #8 PFH or larger fasteners through masonry strap into jamb without penetrating through the jamb into product causing visibility or collateral damage to product.
4. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer or record for the project of installation.
5. Replace #8 x 1" fastener in stationary bracket with #8 x 2 1/2" PPH or greater fastener through stationary bracket and head jamb into wood framing.

General Notes:

1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC) and the industry requirement for the stated conditions.
2. All glazing shall conform to ASTM E1300.
3. At minimum, glazing shall be tempered (3.1mm) insulating glass.
4. Use structural or composite shims where required.

This schedule addresses only the fasteners required to anchor the window to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the window or go to [www.jeld-wen.com/resources/installation](http://www.jeld-wen.com/resources/installation).

DISCLAIMER:

This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

PROJECT ENGINEER:	DATE:	7/31/2016
DRAWN BY:	SCALE:	NTS
J.HAWKINS		
CHECKED BY:	TITLE:	EpicVue Clad Narrow Gliding Patio Door
C.GRAEFSCH		
APPROVED BY:		
D.STOKES		
PART/PROJECT No.:	PLANT NAME AND LOCATION:	Bend-OR
D014241		
IDENTIFIER No.:	CAD DWG. No.:	REV: A
--	CUSJCLNGPD Cert	SHEET

**JELD-WEN** 3737 LAKEPORT BLVD.  
KLAMATH FALLS OR, 97601  
PHONE: (800) 535-3936