



MAXIMUM FRAME	DP	IMPACT
73.9375" x 81.6875"	+60/-60	NO

HVHZ

- Installation Notes:**
1. Seal flange/frame to substrate. Sill shall be set on a continuous serpentine bead of structural grade silicone caulk (typ.).
 2. Use #8 SFH or greater fastener through the head & side jambs with sufficient length to penetrate a minimum of 1 1/2" into the wood framing. For 2x wood frame substrate (min. S.G. = 0.42)
 3. Use (1) #8 TFH or greater fastener through each Hinge with sufficient length to penetrate a minimum of 1 1/2" into the wood framing.
 4. Host structure (wood buck, masonry, steel) to be designed and anchored to properly transfer all loads to the structure. The host structure is the responsibility of the architect or engineer of record for the project of installation.

- General Notes:**
1. The product shown herein is designed, tested and manufactured to comply with the wind load criteria of the adopted International Building Code (IBC), the International Residential Code (IRC), the Florida Building Code (FBC) Including HVHZ and the Industry requirement for the stated conditions.
 2. All glazing shall conform to ASTM E1300.
 3. Use structural or composite shims where required.

This schedule addresses only the fasteners required to anchor the unit to achieve the rated design pressure and impact performance (where applicable) up to the size limitations noted. It is not intended as a guide to the installation process and does not address the sealing consideration that may arise in different wall conditions. For the complete installation procedure, see the instructions packaged with the unit or go to www.jeld-wen.com.

DISCLAIMER:
This drawing and its contents are confidential and are not to be reproduced or copied in whole or in part or used or disclosed to others except as authorized by JELD-WEN Inc.

"AS TESTED"

DRAWN BY: I. BROOKS	DATE: 03/06/20
CHECKED BY: D. VEZO	SCALE: NTS
APPROVED BY: D. VEZO	TITLE: ARCHITECTURAL FIBERGLASS INSWING OPAQUE DOUBLE DOOR
PART/PROJECT No.:	3737 LAKEPORT BLVD.
IDENTIFIER No. K3238.01-301-47	JELD-WEN KAMATH FALLS OR, 97601 PHONE: (800) 535-3936
CAD DWG. No.:	REV:
SHEET	1 OF 1