


Installation Instructions for PV-4-C12

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.






Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 12 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Pop Vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963

Website: roofvents.com Email: sales@roofvents.com


5777-5

Installation Instructions for PV-6-C12

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.






Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 12 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Pop Vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.





Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 12 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Aura vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963

Website: roofvents.com Email: sales@roofvents.com


5777-5

Installation Instructions for PV-10-C12

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.





Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 12 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Aura vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963

Website: roofvents.com Email: sales@roofvents.com


5777-5

Installation Instructions for PV-12-C12

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.





Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 12 (tolerance :1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Aura vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.






Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 16 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Aura vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.






Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 20 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Aura vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.






Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 20 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Aura vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963

Website: roofvents.com Email: sales@roofvents.com


5777-5

Installation Instructions for PV-20-C12

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.






Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 24 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Aura vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963

Website: roofvents.com Email: sales@roofvents.com


5777-5

Installation Instructions for PV-24-C12

For EPDM, PVC or TPO Membrane Flat Roofs


Step 1:

Turn the vent upside down and make a cardboard template from the flange. The template should be the same size as the flange with the hole in the middle.




Step 2:

Using the template, trace the square and circle onto the roof as shown.






Step 3:

Remove cardboard template to show the square and circle pattern.



Step 4:

With a razor blade, cut the circle traced out onto the membrane and remove. Then with a reciprocating saw, cut a hole in the roof deck and remove all debris.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963


Website: roofvents.com Email: sales@roofvents.com

5777-5

For EPDM, PVC or TPO Membrane Flat Roofs


Step 5:

Apply sealant within the square flange outline.




Step 6A:

Place vent within the square outline & attach using a screw gun or drill.





6B:

Required Screw: #10 x 1.5" steel sheet metal screw
Total number of screws required = 24 (tolerance : 1/2")



Step 7:

Apply roofing cement over the screws and edge of flange. This is how the Aura vent should look when finished.



Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963

Website: roofvents.com Email: sales@roofvents.com

5777-5